

ECOLOGICALL 41 DESCALER - DISINCROSTANTE

allegrini
HO.RE.CA. & FACILITIES

ACIDIC DESCALER



- **Easy-to-use limescale remover.**
- **It does not ruin steel and aluminum.**
- **Easy to rinse.**



SUGGESTIONS

Useful for the limescale removal from water heaters, pasta cookers and boilers.

DESCRIPTION

The efficiency of serpentine heating and dishwasher washing and rinsing tubes is influenced by limescale presence. A regular maintenance ensures energy saving and cleaner dishware. ECOLOGICALL 41 DESCALER - DISINCROSTANTE is an acidic-based liquid descaler for the complete removal of limescale residues. The combination between the right acidity and the detergent effect permits the elimination of greasy and limescale residues that deposit in the most hidden parts of the dishwasher: plugs, filters, serpentines etc. Easy to rinse.

ECOLOGICALL 41 DESCALER - DISINCROSTANTE belongs to the EcologicAll line, formulated by the Allegrini Research&Development labs. This line is composed of ecofriendly products in compliance with CAM criteria (minimum environmental criteria), environmental requirements that involve the whole product life production cycle, from the formulation to the packaging.

Allegrini cares the environment: the formula is ecofriendly and the packaging is made with 35% of recycled plastic.

ECOLOGICALL 41 DESCALER - DISINCROSTANTE

ACIDIC DESCALER

PHYSICAL AND CHEMICAL CHARACTERISTICS

Aspect	Clear Liquid
Colour	Colourless
Odour	Light, characteristic
Specific weight	1.030 ± 0.05 g/ml
Water solubility	Complete at every ratio
pH	< 1.5



FOAMING POWER

Null

AVAILABLE PACKAGING

Box with 4 cans of 5L - 016EC410020

USE MODALITY

Dishwashing machine:

Add 1,5-2,5L of product every 10L of hot water in the dishwasher tank.

Turn off the detergent dosing pump and turn on the washing machine for 15/20 minutes. Rinse thoroughly. Finally, turn on the detergent dosing pump.

Double-boiling cooker:

Dilute the product from 15% up to 25% in hot water according to the incrustations level to be removed. Let it work for about 20 minutes, then rinse. In case of stubborn incrustation, use a spatula to remove them.